



Pushbuttons (PB)



PB5

Part # **Description**

- PB5** 2" Round Momentary Red Button, DPDT, Illuminated
- PB5E** 2" Round Momentary Red Button, DPDT
- WCC** Weather Cover Single Gang
- WBB** Gasketed Back Box Single Gang

10 Amp Rated Contacts



EEB2

Emergency Exit Buttons

- Emergency Exit Buttons offer additional safety, as required by code, for possible malfunction of motion exit sensor.
- Mounted next to a door
- Momentarily pressing the button releases door for 30 seconds
- Retriggerable
- Single gang or Narrow stile
- SPST 3 Amp wet N/C contacts
- Operates on 12 or 24 VDC (must be same voltage as the installed lock)
- For indoor use only
- **UL Listed**



EEB3N

Part # **Description**

- EEB2** 2" Square Emergency Exit Green Button
- EEB3N** 1 x 3/4" Rectangle Emergency Exit Green Button, *Narrow Stile*

Approvals and Listings

- EEB2 & EEB3N - Underwriter's Laboratories: File BP7041 (UL 294)
- California State Fire Marshall: 3774-0923:104

Weather Option: WCC and WBB available for all single gang pushbuttons, keyswitches and keypads. See page 46.