




# Pushbuttons (PB)



**PB**

**Part #**      **Description**

- PB**            1-1/2" Round Momentary, DPST, Green Button, Illuminated
- PBA**        1-1/2" Round Alternate, DPST, Green Button, Illuminated
- PBR**        1-1/2" Round Momentary, DPST, Red Button, Illuminated
- PBRA**      1-1/2" Round Alternate, DPST, Red Button, Illuminated

*7 Amp Rated Contacts*




**PB2**

**Part #**      **Description**

- PB2**            2" Square Momentary, SPDT, Green, Illuminated
- PB22**        2" Square Momentary, DPDT, Green, Illuminated
- PB2H**        2" Square Momentary, SPDT, Blue Button, Illuminated, Handicap
- PB2E**        2" Square Momentary, SPDT, Green Button
- PB2EH**      2" Square Momentary, SPDT Blue Button, Handicap


*10 Amp Rated Contacts*



**PB2H**

**PB2E**

**PB2EH**



**PB3**

**Part #**      **Description**

- PB3**            1" x 3/4" Rectangle Momentary, DPST, Illuminated
- PB3A**        1" x 3/4" Rectangle Alternate, DPST, Illuminated
- PB3E**        1" x 3/4" Rectangle Momentary, DPST
- PB3EA**      1" x 3/4" Rectangle Alternate, DPST
- PB3ER**      1" x 3/4" Momentary, DPST, *Surface Mount*
- PB3EAR**    1" x 3/4" Alternate, DPST, *Surface Mount*

*3 Amp Rated Contacts*



**PB3ER**

**PB3E**

Weather Option: WCC and WBB available for all single gang pushbuttons, keyswitches and keypads. See page 46.

PB - PB2 - PB3