




Pushbuttons (PB)



PB

Part #	Description
PB	1-1/2" Round Momentary, DPST, Green Button, Illuminated
PBA	1-1/2" Round Alternate, DPST, Green Button, Illuminated
PBR	1-1/2" Round Momentary, DPST, Red Button, Illuminated
PBRA	1-1/2" Round Alternate, DPST, Red Button, Illuminated

7 Amp Rated Contacts



PB2

Part #	Description
PB2	2" Square Momentary, SPDT, Green, Illuminated
PB22	2" Square Momentary, DPDT, Green, Illuminated
PB2H	2" Square Momentary, SPDT, Blue Button, Illuminated, Handicap
PB2E	2" Square Momentary, SPDT, Green Button
PB2EH	2" Square Momentary, SPDT Blue Button, Handicap


10 Amp Rated Contacts



PB2H

PB2E

PB2EH



PB3

Part #	Description
PB3	1" x 3/4" Rectangle Momentary, DPST, Illuminated
PB3A	1" x 3/4" Rectangle Alternate, DPST, Illuminated
PB3E	1" x 3/4" Rectangle Momentary, DPST
PB3EA	1" x 3/4" Rectangle Alternate, DPST
PB3ER	1" x 3/4" Momentary, DPST, <i>Surface Mount</i>
PB3EAR	1" x 3/4" Alternate, DPST, <i>Surface Mount</i>

3 Amp Rated Contacts



PB3ER

PB3E

Weather Option: WCC and WBB available for all single gang pushbuttons, keyswitches and keypads. See page 46.

PB - PB2 - PB3